



INSTALLATION INSTRUCTIONS

**LEXUS LX450 (1997)
TOYOTA LAND CRUISER (1997)**

PART NUMBER: TY-74-97

**VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM**

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM™.
All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: # 1Phillips screwdriver, small flat head screwdriver, hook tool, 5/16" open end wrench.

PARTS INCLUDED: Pro.Fit VSM™, instructions.

LOCATION: To the right of the radio.

STEP 1.

Begin by removing ashtray by pushing on lever and sliding out. Remove two (2) Phillips screws located inside the ashtray cavity. Just above the radio and inside the top of the bezel cubby hole, two (2) tabs must be released. Use the small screwdriver to pull right tab down to release while at the same time, use the interior hook tool to pull left tab down. Continue pulling to slide left tab down. Continue pulling to slide cubby hole out. Set aside.



STEP 2.

Remove two (2) additional Phillips screws behind cubby hole. With fingers pull on top section of radio trim bezel, working around to release three (3) clips [two (2) on left and one (1) in middle.] Do not disconnect wiring. Let hang aside.



STEP 3.

Using the 5/16" open end wrench, loosen (do not remove) two (2) hex head bolts located to the right of the radio, running horizontally toward the glove compartment. Loosen just enough to slide the Pro.Fit VSM™ behind the bolt heads. Slide Pro.Fit VSM™ behind bolts and tighten.



STEP 4.

Reassemble bezel. Replace screws and ashtray. Attach hang-up cup onto Pro.Fit VSM™.

This completes the installation of your Pro.Fit VSM™.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM™. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876

Web Address: www.pro-fit-intl.com