



DODGE DAKOTA (2001-2004) (A/T ONLY) DODGE DURANGO (2001-2003) (A/T ONLY)

PART NUMBER: DG-71-01

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.


Pro.Fit logo and part number will be right side up and readable when installed.

TOOLS REQUIRED: Torx T-15 driver, 7mm socket and driver, 5/64" drill bit and drill, #2 Phillips screwdriver, hook tool, protective cloth, marking pen, small file or Exacto Knife (for 2003 models only).


PARTS INCLUDED: Pro.Fit VSM®, instructions, two (2) # 8 x 1/2" screws.

LOCATION: Below the radio

STEP 1. Open the driver's side door and locate the fuse panel on the left end of the dash. Remove the panel's cover by using the finger hole and pulling outward. Next, remove the panel under the steering column. Locate and remove three (3) #15 Torx screws from the bottom edge of the panel. The top of the panel is held in place by three (3) clips (see photo #1) that release by pulling the panel out towards you.



STEP 2. Remove the two (2) 7mm screws located in the uppermost portion of the instrument cluster. Set the parking brake and put the gear shift into neutral. Place a protective cloth on top of the dash. Next, remove the trim bezel surrounding the radio and instrument cluster. Starting at the top of the bezel, insert a hook tool behind the bezel and pull gently outward. Work your way completely around the bezel with a hook tool, pulling outward to release all retainer clips. After all the clips are released, pull the bezel forward. Unhook the wiring to the headlight switch and set the bezel on top of the dash, covered with a protective cloth. Place the Pro.Fit VSM® against the flat spot to right of the power outlet, as shown in photo # 2.



STEP 3. THIS STEP IS FOR 2003 MODELS ONLY!!! See Photo # 3. With the VSM against the flat spot, mark the left and right side of the VSM where it touches the dash pad. With a small file or Exacto Knife, trim the area between your marks, approximately 1/8" deep. The VSM® should be flush with the dash pad. Go to STEP 4.




STEP 4. Using the VSM® as a guide, mark the location of the two (2) pilot holes. Drill two (2) pilot holes at the marked location using a 5/64" drill bit and drill. These holes should be about 1/2" deep. Align the VSM® over the pilot holes, insert two (2) # 8 x 1/2" screws and tighten. Reassemble the dash in reverse order, remembering to reconnect the wiring to the head light switch.



This completes the installation of your Pro.Fit VSM®.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© Pro.Fit International, Eagan, MN 2003

